

# Valve accessory Operating element

hand lever, mechanical operation Type series: HHC-...



- All external parts with zinc-nickel plating according DIN EN ISO 19598 or stainless steel
- Available in lockable and non-lockable versions
- Use for standard valve cartridges of the W1..., W2... and W\_22... series
- The hand lever can be rotated 360° and it can be replaced without opening the hydraulic circuit
- Sealable in unactuated position

# Description

The hand lever of the type series HHC-... is a screw on lever, which can be used with various standard valve cartridges if required. When the lever is released, it automatically returns to the non-operated position.

With the lockable version, the lever can be locked in the actuated position. The hand lever can be retrofitted without opening of the hydraulic circuit. (refer to the section "Installation instructions")

## **Symbol**





## Technical data

General characteristics	Description, value, unit
Function group	Valve accessory
Function	Operating element
Controls	mechanical operation
Characteristic	hand lever
Thread size	several, see chapter "Dimensions, Sectional View"
Mounting attitude	see Chapter "Installation instructions"
Weight	0,3 kg




General characteristics	Description, value, unit
Minimum ambient temperature	- 30 °C
Maximum ambient temperature	+ 50 °C
Surface protection	All external parts with zinc-nickel plating according DIN EN ISO 19598 or stainless steel

# Dimensions and sectional view


Beispiel für die Masseinheit: Exampel for the dimensional units:

0.79 = 0.79 mm millimeter (.031) = 0.031" inch

Handhebel "HHC-...-M16x1.5" (W1... , W2...) Hand lever "HHC-...-M16x1.5" (W1... , W2...)



Handhebel "HHC-...-M16x1.0" (W\_22...) Hand lever "HHC-...-M16x1.0" (W\_22...)






#### Installation instructions

- 1. Remove retaining nut. s6
- 2. Seal 2 and solenoid coil 3 must be fittet according to valve data sheet.
- 3. Unscrew nut s3 from the lever s4.
- 4. Mount the nut 33 on to the valve and tighten to the required torque.
- 5. Mount the lever, tighten nut 4 slightly.
- 6. Turn lever to the desired position. Tighten nut sate to the required torque while holding the nut sate with the wrench.
- 7. Use the adjusting screw A to align the lever 90° to the valve axis

- 9. Swivel the lever as far as it will go in the direction of the solenoid coil s1 and hold it in the actuated position.
- 10. Tighten the adjusting screw **B** as far as it will go and then turn it back by 1/3 of a turn.
- 11. Check valve and hand lever for function and correct switching behavior.



#### (i) NOTE

 $^{\$5}$  = Hole (Ø2 mm / Ø0.079") for sealing by the customer. (Seal not included in the scope of delivery)


# (i)

#### NOTE!

The adjusting screw A and B are self-locking. Frequent adjustment can reduce self-locking.



# Ordering code



#### info.ch@bucherhydraulics.com

www.bucherhydraulics.com

© 2025 by Bucher Hydraulics AG Frutigen, 3714 Frutigen, Switzerland

All rights reserved.

Data is provided for the purpose of product description only, and must not be construed as warranted characteristics in the legal sense. The information does not relieve users from the duty of conducting their own evaluations and tests. Because the products are subject to continual improvement, we reserve the right to amend the product specifications contained in this catalogue.