

Installation information



ATTENTION!

You must maintain the specified positional and diametral tolerances. To ensure trouble-free operation of the screw-in cartridges, we strongly recommend that pilot drilling, boring, reaming and cavity thread-cutting are always performed in one setup.



NOTE!

The cavity type C1620 complies with the standard according to ISO 17209: 1 5/16-01-0-13 and NFPA/T3.5.50: 1.312-01-0-09.



NOTE!

We offer form toolsets for sale or hire. For further information, see data sheet 520-P-000050.