

Installation information



ATTENTION!

You must maintain the specified positional and diametral tolerances. To ensure trouble-free operation of the screw-in cartridges, we strongly recommend that pilot drilling, boring, reaming and cavity thread-cutting are always performed in one setup.



IMPORTANT!

We offer form tool sets for sale or hire. For further information, see data sheet 400-P-040011.



NOTE!

Cavity type to factory standard.



ATTENTION!

It is essential that the G1/4" thread be cut with a tap. Thread milling is not permitted, because the circular interpolation can produce unacceptable roundness errors.